


Instructions for FA-130T ABC 4 Stroke Cycle Engine

Thank you for your purchase of the Saito FA-130T engine. We feel that you have made a wise purchase and one that will last for an extended period of time through hard usage. Please read and become familiar with these instructions prior to operation of the engine. Follow closely the break-in procedures and maintenance instructions while we will repair this engine without any cost, if you have a manufacturing defect.



The FA-130T engine utilizes a single throw crank shaft, like all full sized radial engines. Because of this design, the engine is simple in construction, light in weight, and highly efficient. To maintain a positive crankcase pressure, and eliminate harmful blowby gasses, and to ensure complete and smooth lubrication throughout the engine, and protect from inside rust, a diaphragm system air pump is employed (Patent applied for).

- Cylinder : Hard chrome plated for better cool running and light weight
- Piston : High silicon content aluminum
- Crankshaft : Twin ball bearing supported
- Cylinder Head : Hemispherical for increased power
- Cam Gear : Forward placed twin cams for light weight
- Valves : Large diameter for power and efficiency
- Carburetor : Twin carburetor

FA-130T(21.2cc) Specifications

- Bore : 24.8mm × 2
- Stroke : 22mm × 2
- Maximum RPM : 11,000rpm
- Useful RPM Range : 2,300~10,500rpm
- Fuel Flow : Full throttle/1 minute. Approx. 14cc fuel. 10% Nitro
- Weight : 870 grams approx.

ACCESSORIES FOR FA-130T

- | | |
|--|--------|
| 1. Spanner for tappet adjusting screw | 1 |
| 2. Screwdriver for slowneedle adjustment | 1 |
| 3. Tappet adjusting screw gap gauge (0.1t) | 1 |
| 4. Hexagonal spanner (wrench) (3,2.5,2,1.5) | 1 each |
| 5. Spanner for exhaust & intake pipe nut (M12) | 1 |
| 6. Offset wrench for prop nut (M14) | 1 |
| 7. Engine mount bolts M4×25 & washer M4 | 4 each |
| 8. Blind nuts for mounting bolts (M4) | 4 |
| 9. Needle valve extension bar | 2 |
| 10. Knob for bar | 2 |
| 11. Connector for plug | 1 set |
| 12. Exhaust pipe (R & L) w/gasket | 1 set |
| 13. Glow plug | 2 |
| 14. Engine mount spacer | 4 |

Ⓐ **Fuel** : Any glow engine fuel with a nitro content from 5 ~ 15%. Castor oil based fuels are recommended for the best lubrication.

Ⓑ Plugs :

Due to the operation of 4 stroke engines (1 explosion for 2 revolutions), plug selection is critical for efficient operation.

Ⓒ **Propeller** : Standard for this engine is the 13"×10"~14"×8", 15"×6",


Ⓓ **Engine Mounting** : Use at least 10mm or greater thickness of plywood for mounting the radial engine mount as a fireproof wall and strengthen with triangle wood stock. Use attached parts for fixing. (See diagram)

Ⓔ **Fuel Tank** : Use a 400 ~ 450 cc fuel tank. It is the best that fuel in the fuel tank has the same level as the needle valve.

TWIN CARBURETOR



- (1) An optimum fuel-air mixture for efficient combustion to the right and left cylinders can be individually adjusted by the needle valve.
- (2) Improved output
- (3) Improved performance without plug heat in idle mode (approx. 2,300 rpm).

Explanation of ABC 4 Stroke Cycle Engine



1 Suction Stroke 2 Compression Stroke 3 Expansion Stroke 4 Exhaust Stroke

4 Stroke Cycle engine consists of 4 strokes as illustrated above. Stroke means that piston is moved from the upper dead point to the lower dead point. In case of 4 Stroke Cycle engine, gas condition in cylinder, variation, valve motion, etc., are 4 strokes 2 both ways of piston. After all, 1 cycle is finished every 2 revolutions of crankshaft and returns to the original condition.



How to install an engine

Power source parts right and left, and a large dry battery in capacity (1.5 V FM-(3 H)) or Nickel-Cadmium battery UM1 is used for each of them.

Moreover, use an electric wire (0.5 VSF low resistance wire) or bigger ones. Unless you use it, electric current is short and a battery is wasted for start troubles. Make sure to start the both cylinders together while one side start is strictly prohibited.

Ⓕ Engine Start Use always the filler pressure. For your safety, use a pair of gloves for starting

a) Manual Start

- Rotate the propeller clockwise and set it in a vertical position by tightening nuts when it gets compressed.
- Fully open the throttle valve.
- Open main needle about 5 turns.
- Priming
Pull out a stopper, and prime fuel about 5 cc with a syringe. Be sure to put the stopper on.
- Confirm the fuel is not compressed. (When fuel is taken in too much, it may be compressed and may damage rod, etc.)
- Slightly open the throttle valve from the Low speed. (This is a powerful engine. If the throttle is opened too much, the aircraft may make a dashing start)
- Rotate the propeller clockwise 180 degrees back from the position where it is compressed. (Upper side)
- Switch on the electric source.
- Crank the propeller clockwise and the engine will start running rightly.

b) Start by starter (Never do priming)

- Set the throttle valve at the Slowest position.
- Confirm that the starter is rotating counter-clockwise and run the engine idle for five to seven seconds. It then chokes.
- Heat the plug and open the throttle valve from the Slowest Speed to about one-fourth for starting.

Important

For your safety, we recommend use of the starter.

c) How to Operate and Adjust the Carburetor.

The carburetor is pre-adjusted for best performance. But, a little readjustment may be necessary according to the installation position, type of fuel, or weather conditions.

Ⓖ Adjusting Main Needle Valve

Open the main needle valve about 5 turns depending upon the plugs used and a type of fuel. Set the throttle lever to the low-speed position to set plug heat. Forcibly give forward turns to the propeller. When the engine starts operation, set the throttle lever to the maximum-speed position. Either right or left needle valve may be adjusted first. Explanation proceeds with adjustment of the left needle valve. Loosen the needle valve to a 1/2 turn to enrich a fuel-air mixture. Gradually, throttle it until the peak value is obtained. Take the same procedure for the right needle valve as for the left one until the peak value can be obtained. Adjust the right and left needle valves once more until the peak value can be obtained. After that, loosen both needle valves 1 or 2 divisions (knurled heads). Finally, adjust the right and left needle valves repeating the above operation 2 or 3 times.

- Close the throttle slowly and adjust idling.

a) The mixture is too rich.

When the throttle is fully opened too quickly from the Slowest Speed, the carburetor issues white smoke and dull noise, and revolution increases intermittently.


Turn the idling adjustment valve clockwise with the small screwdriver.

b) The mixture is too lean.

The engine stops when the throttle is set at Slowest Speed. Or, the engine stops when the throttle is fully opened too quickly or it issues dry noise and revolution increases belatedly.

Turn the idling adjustment valve counter-clockwise.

- When idling run is obtained, set the desired slow revolution with the throttle adjustment screws.
- Do the above-mentioned adjustment until the engine revolution promptly responds to operation of the throttle valve.
- When idling, the engine runs more stably by plug heat.
(Use two pieces of Nickel-Cadmium battery UM 2 in a line for power source.)





Adjustment of engine response with the throttle valve.

When suddenly opening the throttle valve fully while the engine is running at idle.

- a. When the revolution speed increases quickly, the engine is normal.
- b. c. and d's troubles and counterplans to.

	Conditions	Causes	Counterplanes
b	<ul style="list-style-type: none"> • Response is intermittent. • Thick gas comes out from the exhaust pipe. • Revolution is slow or instable. 	Caused by rich mixture.	Turn the idling adjustment valve clockwise.
c	<ul style="list-style-type: none"> • Engine stops when the throttle is opened from low to high speed. • Engine stops when the throttle is set at the slowest. • Revolution increases belatedly and suddenly. 	Mixture gas is too light.	Turn the idling adjustment valve counter-clockwise.
d	If the idling dose not continue.	Neither plug nor fuel fits the engine.	Recommend a plug with thick filament

Priming



When tightening bolts, put washers between engine mount and fire wall to minimize depression on fire wall, and for reinforcement.

Engine Usage

Type	Wing Area	Weight(kgs.)	Flying
Scale	50 dm ² ~80 dm ²	4~7	Simple aerobatic
Sport	50 dm ² ~60 dm ²	3.7~4.5	Stunt
Large. light scale, etc.	80 dm ² ~100 dm ²	6~8	Prototypical flight maneuvers

⊙ How to Adjust finely the Needle valve

Too much closure may lead to overheating and cause corrosion of the inner surface. It may also cause knocking. Continual knocking leads to damage to the engine.

First set the needle valve at a position in excess of the normal peak position. Fly the plane for about ten minutes. After landing, run the engine at the maximum rpm to obtain the ideal peak position of the needle valve.

Caution:

- A. Don't adjust the needle valve when the tank is full.
- B. Adjust it when the fuel is low in the tank after a flight.

⊕ Break-in

The break-in procedures for all engines should be followed carefully as a proper break-in will achieve the best, long lasting performance.

After a start of engine running according to the procedure (F), adjust the needle valve to gain rich mixture and keep the engine running at max. 4,000 - 5,000 r.p.m. for the first 20 minutes. (For mainly break-in of a connecting rod and a cam gear) Next is to lean out the mixture to achieve the highest RPM for about 30 seconds, then richen it up again to about 6,000 r.p.m. Repeat this procedure every three minutes or so. For about the first 10 flights, you should not fly at peak RPM as the engine is still wearing in. After about an hour of running, check the valve for proper clearance. The engine should now be broken in and function smoothly at all settings. Sometimes, fasten tightly Propeller Nut, nut of Exhaust Pipe etc. When starting engine, keep spectators away and out of path of rotating prop. Make all engine adjustments from behind rotating prop. Secure all persons against danger.


① Normal Operation and Maintenance

- (a) Since excessively throttling the needle valve causes overheating, adjust it somewhat lower than the peak. (Excessive throttling stops the engine and blow-by gas will be increased, which causes rust for bearings. Refer to the above "How to adjust finely the needle valve.")
- (b) After the first 1 hour of operation, adjust the tappet gap since it has an initial wear. Use the attached open-ended wrench and hexagonal spanner (1.5) to adjust it so that there is a slight gap at compression stroke while the engine is cool. After checking

the gap, tighten the lock nut. Hereafter, follow the procedures in item (b) to check the gap from time to time, and adjust the gap so the gauge (thickness 0.1 mm) passes through the gap.

Running with the gap too large may lower the performance. The tappet gap is a very important element in the maintenance of the four cycle engine.

★ Lubrication inside the Engine and Drainage of Waste Oil



For lubrication of the piston, bearing, cam and gear, etc., lubricating oil which has been mixed in the fuel enters the inside through the piston clearance for lubrication.

(c) Lubricate the rocker arm and valve surroundings as required during inspection.

④ Dismantling



Please do not dismantle the engine. However, pay your attention to the following points in case of dismantling.

- ① When assembling, apply engine oil to the tops of screws and fasten them accordingly (If you fasten screws under dry conditions, screws will be damaged so that they need oil)
- ② Position piston, rod, rocker arm, pin, push rod, tappet, etc., in the original positions, because they are accustomed to their respective positions even if they are common parts. This is a knack to assemble them in the original conditions. When you assemble it, apply engine oil to each part for assembly.
 - (1) Cleaness (2) Apply engine oil to each section (3) Fasten screws averagely. Do not fasten too tight. These are important steps to assemble your engine.
- ③ If you do not use your engine for a time, take out plug, crank case rear cover so as to wash them completely with petroleum. After clearing, blow away petroleum with air and apply engine oil to them for assembly. Then, pack it in a vinyl bag for storage.



Warning After starting the engine, operate it behind the propeller. It is dangerous if the propeller will fly. Moreover, tighten the screws occasionally. Use a starter or a pair of gloves for starting. Always, set an interval of the tappet within 0.1 as shown. Please pay your attention to safety and other troubles.

Cam Gears Replacement. When facing engine, assemble the right cam gear first as follows:

1st (Right Cylinder)



2nd (Left Cylinder) Revolution



1st (Right Cylinder)

Crank throw at right cylinder top dead center. Insert cam shaft assembly tool into the exhaust pushrod bushing, and rotate camshaft until tool falls into oil hole in camshaft. With camshaft in position and crank at TDC, the gears will mesh at the proper timing point. Bench marks are located on the gears for reference.

2nd (Left Cylinder)

Rotate crankshaft 180 degrees to the arrow mark. Insert timing tool into the intake side of the pushrod opening. Rotate cam gear until the tool enters the oil hole of the camshaft. Gears are now lined up with the bench marks. Study diagrams carefully.

Please note that these specifications are subject to change without prior notice.

SAITO SEISAKUSHO, LTD.

22-7, Tokagi, 3-chome, Ichikawa-Shi, Chiba Prefecture, Japan.

Telephone No. 0473-78-4156 TELEX No. 02993227 FAX No. 0473-78-4155

Saito FA-130T Parts List

No.	Description	Q'ty	No.	Description	Q'ty
01	Cylinder (left)	1	41	Rocker arm	4
02	Cylinder (right)	1	42	Rocker arm screw & nut	4ea.
06	Piston	2	43	Rocker arm pin	4
07	Piston pin	2	46	Valve (in & out)	4
08	Piston pin retainer	4	47	Valve spring & keeper & Retainer	4ea.
09	Piston ring	2	48	Valve retainer	
10	Connecting rod	1	49	Rocker arm cover	4
11	Linked conrod	1	64	Air pump assembly	1set
14	Cylinder screw set	2set	65	Air pump housing	1set
15	Crankcase	1	66	Diaphragm & Check valve rubber set	1set
17	Rear cover	1set	67	Diaphragm pushrod & Return spring	1ea.
19	Breather nipple	1	68	Check valve (in & out)	1set
20	Front bearing	1	69	Intake manifold (left)	1
22	Rear bearing	1	70	Intake manifold (right)	1
23	Crankshaft	1	73	Muffler (left)	1
27	Taper collet & Drive flange	1ea.	74	Muffler (right)	1
28	Prop washer & nut	1ea.	79	Muffler gasket	2
31	Crankcase screw set	1set	80	Muffler nut	2
32	Engine gasket set	1set	81	Priming harness	1set
33	Cam gear housing	2	82	Carburetor complete	1set
34	Cam gear (left)	1	83	Carburetor body assembly	1set
35	Cam gear (right)	1	85	Full throttle needle	1
36	Cam gear shaft	2	87	Throttle barrel assembly	1set
37	Teflon washer set	1set	88	Throttle lever	1set
38	Tappet	4	91	Carburetor gasket set	1set
39	Pushrod	4	95	Engine mount	1set
40	Pushrod cover & Rubber seal	4ea.			

